



TIPS & TRICKS



SKIP WILBUR

COOLING SANDING PADS

Another way to fight the heat enemy while sanding is to either wait until your sanding paper cools down or to expedite this procedure by spritzing the sandpaper with denatured

alcohol. The alcohol will almost immediately evaporate and will cool down the sanding surface. I usually have a plastic bottle of denatured alcohol within reach of my lathe.

